

Outstanding audio quality

with Philips transcription headphones

The lightweight stethoscope-style headphones use a dual tube design and a center mounted dynamic speaker to deliver sound effectively through both chambers. The hinged, fully adjustable design and the plastic ear tips provide a comfortable fit and minimize the impact on your ears. The extra-long cable (3 m/10 ft) gives you the freedom to move around..

Superior audio quality

- Professional headset that enables concentrated transcription in busy office environments
- ${\boldsymbol{\cdot}}{}$ Neodymium magnet enhances sensitivity and sound quality

For optimal results

- · Lightweight design improves comfort for prolonged use
- $\boldsymbol{\cdot}$ $\,$ Under chin style to fit all ears for better comfort
- · 3 meter/10-foot cable for freedom to move about your desk area



Highlights

Everything you need

Philips accessories are designed to help you make the most of your Philips dictation devices. They guarantee optimal results and ensure that your Philips products enjoy a long life.

Neodymium magnet

Neodymium is the best material for producing a strong magnetic field for greater sensitivity and higher overall sound quality.

Lightweight design

The durable, lightweight quality materials enhance comfort for extended wearing.

Under chin style

Designed for an under-the-chin fit for better comfort.

3 meter/10-foot cable

The 3 meter/10-foot cable gives you the freedom to move around your desk area without having to remove your headset.

Specifications

Sound

Acoustic system: open Magnet type: neodymium Diaphragm: PET dome Voice coil: copper

Sound quality: optimized for voice

reproduction Impedance: 32 Ohm

Maximum power input: 10 mW

Sensitivity: 103 dB Speaker diameter: 14 mm

Type: dynamic

System: single sound system

Connectivity

Cable connection: one-sided Cable length: 3 m/10 ft

Connector: 3.5 mm stereo, right angled

Type of cable: copper

Package contents

Headphones Hanging bracket Single ear clip WEEE information

Compatibility

All Philips desktop dictation and transcription systems Philips Pocket Memo digital voice recorder

Philips Pocket Memo meeting recorder

Green specifications

Compliant to 2011/65/EU (RoHS) Lead-free soldered product

Specifications

Product dimensions: 230 mm × 130 mm × 25 mm/9" × 5" × 1"

Accessories

Philips USB audio adapter LFH9034

© 2017 Speech Processing Solutions GmbH. All rights reserved.

Specifications are subject to change without notice. Philips and the Philips shield emblem are registered trademarks of Koninklijke Philips N.V. and are used by Speech Processing Solutions GmbH under license from Koninklijke Philips N.V. All trademarks are the property of their respective owners.



Issue date 2017-10-30 Version 1.0