

PHILIPS

Transcription headphones

Under-the-chin style

Lightweight design

14 mm speaker driver

3 meter/10-foot cable

LFH0234



Outstanding audio quality

with Philips transcription headphones

The lightweight under-the-chin style headphones with dual sound system are designed to deliver excellent sound quality, with soft ear cushions for wearing comfort, and a hanging bracket that attaches the headset to a monitor.

Superior audio quality

- A 14 mm speaker driver optimizes high audio quality
- Gold-plated plug ensures an ultra reliable connection
- Neodymium magnet enhances sensitivity and sound quality

For optimal results

- Lightweight design improves comfort for prolonged use
- Under chin style to fit all ears for better comfort
- 3 meter/10-foot cable for freedom to move about your work area



Highlights

14 mm speaker driver

Small enough for optimum wearing comfort, yet large enough to deliver crisp, non-distorted sound, the 14 mm speaker driver is the ideal size to deliver high quality sound.

Gold-plated plug

The precious-metal gold finishing on the plug will produce a more reliable connection for better audio quality.

Neodymium magnet

Neodymium is the best material for producing a strong magnetic field for greater sensitivity and higher overall sound quality.

Lightweight design

The durable, lightweight quality materials enhance comfort for extended wearing.

Under chin style

Designed for an under-the-chin fit for better comfort.

3 meter/10-foot cable

The 3 meter/10-foot cable gives you the freedom to move around your work area without having to remove the headphones.

Specifications

Sound

Acoustic system: open
Magnet type: neodymium
Diaphragm: PET dome
Voice coil: copper
Sound quality: optimized for voice reproduction
Impedance: 64 Ohm
Maximum power input: 2 × 10 mW
Sensitivity: 103 dB
Speaker diameter: 14 mm
Type: dynamic
System: dual sound system

Connectivity

Cable connection: one-sided
Cable length: 3 m/10 ft
Connector: 3.5 mm stereo, right angled
Connector finish: gold-plated
Type of cable: copper

Package contents

Headphones
Hanging bracket

Green specifications

Compliant to 2011/65/EU (RoHS)
Lead-free soldered product

Compatibility

All Philips desktop dictation and transcription systems
Philips Pocket Memo digital voice recorder
Philips Pocket Memo meeting recorder

Specifications

Product dimensions (W × D × H):
226 mm × 130 mm × 25 mm/9" × 5" × 1"
Weight: 100 g/3.5 oz.

Accessories

Philips USB audio adapter LFH9034

