



Philips Pocket Memo
Dictation recorder

Mini cassette

POCKET MEMO

LFH0588



Simply working smarter

with Philips dictation solutions

Mobility and flexibility are critical in today's fast-moving business environments. The Philips Pocket Memo dictation recorder gives you the freedom to work when and where you need to.

Superior audio quality

- Sensitivity switch for conference or close-range recording
- Automatic gain control for adjustment to optimum recording level

Enhance your productivity

- Priority index tone for indicating urgent documents
- End-of-letter index tone for indicating the start of each document and number of recordings
- Professional editing via slide-switch operation
- Turbo wind for fast access to any part of the tape
- Visual indication with LED for showing record status and low battery

Designed for professionals

- LCD tape counter for displaying elapsed recording time
- Audible end-of-tape and low battery warning tones for safe recording
- Voice-activation function for hands-free recording
- Transport lock for avoiding unintentional operation
- Internal recharge of batteries for environment friendly use

PHILIPS
sense and simplicity

Specifications

Connectivity

- Headphones: 2.5 mm
- Microphone: 2.5 mm

Sound

- Acoustic frequency response: 400–5,000 Hz
- Output power: >220 mW

Package contents

- Pocket Memo dictation recorder
- 30 minute mini cassette LFH0005
- 2 × AAA batteries
- Luxury pouch
- Belt clip
- Wrist strap

Specifications

- Product dimensions (W × D × H): 123 mm × 58 mm × 25 mm/4.8" × 2.3" × 1.0"
- Weight: 110 g/3.9 oz.

Accessories

- Telephone pickup microphone LFH9162
- Meeting microphone LFH9172
- Clip-on microphone LFH9173
- Rechargeable batteries LFH9154
- Power supply LFH0142

Highlights

Sensitivity switch

Innovative sensitivity switch for close-range and conference recording with optimal sound quality.

Priority index tone

The priority index tone indicates urgent documents. Your urgent jobs get transcribed first.

Automatic gain control

The automatic gain control lets you adjust to the optimum recording level at any time.

End-of-letter tone

The end-of-letter index tone indicates the start of each document and number of recordings.

Professional editing

Easy and quick file editing via convenient slide-switch operation. It offers a fast response and is designed for single-handed operation.

Fast access

The turbo wind function allows very fast and simple access to any part of your tape.

LED indication

The status LED always shows if your battery is running low and the record status.

LCD tape counter

The time elapsed is always shown on the LCD tape counter for a perfect overview.

Warning tones

The warning tones for end-of-tape and low battery status ensure that no dictation is cut off.

Voice-activation

Voice-activated recording is a convenience feature for hands-free recording. When enabled, recording will start automatically when you start speaking. Recording stops automatically after you stop speaking and restarts automatically when you start speaking again.

Transport lock

With the transport lock activated, your dictation recorder is protected from unintentional operation.

Internal recharge

Help protect the environment and save your money by simply recharging the batteries of your device instead of buying new batteries (optional Philips rechargeable batteries LFH9154 required).

